

QUICK REFERENCE GUIDE FOR THE DIMPLEX DF2603 ELECTRIC FIREPLACE MANUAL CONTROLS

A. MAIN ON/OFF SWITCH

The ON/OFF SWITCH supplies power to all fireplace functions (Heater/Flame).

B. FLAME ACTION CONTROL

Turn the flame action control knob to adjust the flame speed to the desired level.

C. INTERIOR LIGHT CONTROL


Turn the interior light control knob to increase or decrease the brightness of the interior light.

D. HEATER CONTROL SWITCH

Turn heater on or off.

E. HEATER THERMOSTAT CONTROL

To adjust the temperature to your individual requirements, turn the thermostat control clockwise all the way to turn on the heater. When the room reached the desired temperature, turn the thermostat knob counter clockwise until you hear a click. Leave in this position to maintain the room temperature at this setting. For additional heat, turn clockwise until you hear the click again and the heater will turn on.



Return to www.electricfireplaces.com